

# PREPARE & FINISH

## THE PERFECT PREPARATION AND FINISH FOR ADHESIVES AND SEALANTS

- Cleaning, degreasing and smoothing
- Professional smoothing of all sealants
- Can be painted over without rinsing\*
- Handy packaging with high efficiency (Bag-on-Valve)




## GENERAL INFORMATION

### Product description

Prepare & Finish is pH neutral, therefore safe on every surface, compatible with every type of adhesive or sealant and removes both fine dust and grease as well as finger marks. Cleaning and degreasing with Prepare & Finish ensures perfect bonding without risk of staining. Smoothing with Prepare & Finish ensures a perfectly smooth and closed joints, accelerates the curing of polymers and reduces the risk of mould growth on sanitary joints. Contains no propellants, is biodegradable and non-toxic.

\*Can be painted over without rinsing if the substrate permits.



## Available packages & colors

SKU	EAN	Description
120050296	5414195015926	Prepare & Finish - aerosol (Bag on Valve) 400ml

## Application

- Degreasing and cleaning before bonding and sealing.
- Smoothing of joints.
- Compatible with e.g. MS-polymers, silicones, acrylic sealants, PU adhesives, etc.

## TECHNICAL INFORMATION

### Specifications

- Composition: aqueous complex of surfactants and alcohols.
- Form: liquid.
- Colour: transparent.
- Odour: characteristic.
- Relative density (at +20°C): 1.
- pH: 7 (neutral).
- Consumption per 400ml:
  - +/- 70 running meters (preparation and finishing).
  - +/- 12 m<sup>2</sup> (cleaning before gluing).
- Shelf life: 24 months, dry, cool and frost-free.

### Technical data sheet

[prepare-finishnovatechtecvc2024-10-04-15-29-10en-ie.pdf](#)

### Detergent sheet

[website-prepare-and-finish-67037-rev001.pdf](#)

### Safety data sheet

[prepare-finish-sds-en-251001.pdf](#)

## INSTRUCTIONS

### Cleaning before bonding and sealing

- Remove as much loose dirt as possible with a brush or cloth.
- Spray the surface. When gluing, treat both surfaces.
- Leave for 30 to 60 seconds.
- Rub away the loosened contamination with a clean microfibre cloth.
- Allow to evaporate for a few minutes before applying adhesive or sealant.

### Smoothing of joints

- Moisten the spatula, applicator tool or finger with Prepare & Finish.
- Smooth the joint and remove excess material.